


**Art.Nr. ORIGINAL SUPPLIES LASER & INKJETPRINTER**


HP-51625A	HP Print Cart. 51625AE	→	DWC/310/20/540/50C/60C/DJ310/20/400/L/500C/40/50C/60C	3-colours	
HP-51626A	HP Print Cart. 51626AE	→	DWC/520/40/50C/60C/DJ+/200/20/400/L/500/ C/10/20/40/550C/60C/600/OJLX/350	black	(1 x 40ml)
HP-51629A	HP Print Cart. 51629AE	→	DJ600/60C/70C/90C/DW600/60C/70C/OJ500/90/635	black	(1 x 40ml)
HP-51633M	HP Print Cart. 51633M	→	DJ310/ 320/340/DW310/320	black	
HP-51639A	HP Print Cart. 51639A	→	PJ/XL300	black	
HP-51639C	HP Print Cart. 51639C	→	PJ/XL300	cyan	
HP-51639M	HP Print Cart. 51639M	→	PJ/XL300	magenta	
HP-51639Y	HP Print Cart. 51639Y	→	PJ/XL300	yellow	
HP-51640A	HP Print Cart. 51640AE	→	DJ230/50C/330/50C/430/50C/55CA/650C/PS/1200C/PS	black	
HP-51640C	HP Print Cart. 51640CE	→	DJ1200C/PS/1600C/CN/CM	cyan	
HP-51640M	HP Print Cart. 51640ME	→	DJ1200C/PS/1600C/CN/CM	magenta	
HP-51640Y	HP Print Cart. 51640YE	→	DJ1200C/PS/1600C/CN/CM	yellow	
HP-51641A	HP Print Cart. 51641AE	→	DJ850C/20CXII/70CXII/1100c/Pro1150c	3-colours	
HP-51644C	HP Print Cart. 51644CE	→	DJ350C/450C/55CA/750C/PLUS/55CM	cyan	
HP-51644M	HP Print Cart. 51644ME	→	DJ350C/450C/55CA/750C/PLUS/55CM	magenta	
HP-51644Y	HP Print Cart. 51644YE	→	DJ350C/450C/55CA/750C/PLUS/55CM	yellow	
HP-51645A	HP Print Cart. 51645AE	→	DJ700/20C/50C/PLUS/55CM/815C/820CXII/50C/70CXII/90C/ 1100C/20C/1220C/1600C/CN/CM/PRO1150C	black	(1 x 42ml)
HP-51649A	HP Print Cart. 51649AE	→	DW600/60C/70C/DJ600/10C/60C/70C/90C/OJ500/90/635	3-colours	
HP-51650C	HP Print Cart. 51650CE	→	DJ250C/650C/PS	cyan	
HP-51650M	HP Print Cart. 51650ME	→	DJ250C/650C/PS	magenta	
HP-51650Y	HP Print Cart. 51650YE	→	DJ250C/650C/PS	yellow	
HP-C1806A	HP Photo Cart. C1806A	→	DJ2000CP/500CP/3000CP/500CP	black	
HP-C1807A	HP Photo Cart. C1807A	→	DJ2000CP/500CP/3000CP/500CP	cyan	
HP-C1808A	HP Photo Cart. C1808A	→	DJ2000CP/500CP/3000CP/500CP	magenta	
HP-C1809A	HP Photo Cart. C1809A	→	DJ2000CP/500CP/3000CP/500CP	yellow	
HP-C1816A	HP Photo Cart. C1816AE	→	DJ690C/93C/94C	3-colours	
HP-C1823DE	HP Print Cart. C1823DE	→	DJ720C/815C/890C/1120C	colour	(1 x 30ml)
HP-C1892A	HP Photo Cart. C1892A	→	DJ2000CP/500CP/3000CP/500CP	black pigmentierte Tinte	
HP-C1893A	HP Photo Cart. C1893A	→	DJ2000CP/500CP/3000CP/500CP	cyan pigmentierte Tinte	
HP-C1894A	HP Photo Cart. C1894A	→	DJ2000CP/500CP/3000CP/500CP	magenta pigmentierte Tinte	
HP-C1895A	HP Photo Cart. C1895A	→	DJ2000CP/500CP/3000CP/500CP	yellow pigmentierte Tinte	
HP-C6578AE	HP Print Cart. C6578AE	→	P1000/P1100/DJ1220C PhotoSmart	high capacity	colour
HP-C6578DE	HP Print Cart. C6578DE	→	P1000/P1100/DJ1220C PhotoSmart		colour
HP-C6614DE	HP Print Cart. C6614DE No.20	→	DJ610C		black
HP-C6615DE	HP Print Cart. C6615DE No.15	→	DJ840C		black
HP-C6625AE	HP Print Cart. C6625AE No.17	→	DJ840C		colour
HP-C6628AE	HP Print Cart. C6628AE No.19	→	DJ350C/C8I		black
HP-92261A	HP Print Cart. 92261A	→	QJ/Plus/TJ/Plus		black




**Art.Nr. ORIGINAL SUPPLIES LASER & INKJETPRINTER**


HP-C4800A	HP Printhead C4800AE NO.10	→ 2000C/CN/2500C/CM	black	
HP-C4801A	HP Printhead C4801AE NO.10	→ 2000C/CN/2500C/CM	cyan	
HP-C4802A	HP Printhead C4802AE NO.10	→ 2000C/CN/2500C/CM	magenta	
HP-C4803A	HP Printhead C4803AE NO.10	→ 2000C/CN/2500C/CM	yellow	
HP-C4820A	HP Printhead C4820A NO.80	→ DJ1050C/1055CM	black	
HP-C4821A	HP Printhead C4821A NO.80	→ DJ1050C/1055CM	cyan	
HP-C4822A	HP Printhead C4822A NO.80	→ DJ1050C/1055CM	magenta	
HP-C4823A	HP Printhead C4823A NO.80	→ DJ1050C/1055CM	yellow	
HP-C4841A	HP Print Cart. C4841AE NO.10	→ 2000C/CN/2500C/CM	cyan	(1 x 28ml)
HP-C4842A	HP Print Cart. C4842AE NO.10	→ 2000C/CN/2500C/CM	yellow	(1 x 28ml)
HP-C4843A	HP Print Cart. C4843AE NO.10	→ 2000C/CN/2500C/CM	magenta	(1 x 28ml)
HP-C4844A	HP Print Cart. C4844AE NO.10	→ 2000C/CN/2500C/CM	black	(1 x 69ml)
HP-C4871A	HP Print Cart. C4871A NO.80	→ DJ1050C/1055CM	black	(350ml)
HP-C4846A	HP Print Cart. C4846A NO.80	→ DJ1050C/1055CM	cyan	(350ml)
HP-C4847A	HP Print Cart. C4847A NO.80	→ DJ1050C/1055CM	magenta	(350ml)
HP-C4848A	HP Print Cart. C4848A NO.80	→ DJ1050C/1055CM	yellow	(350ml)
HP-C4911A	HP Print Cart. C4911A NO. 82	→ DnJ500/PS/800/PS	cyan	
HP-C4912A	HP Print Cart. C4912A NO. 82	→ DnJ500/PS/800/PS	magenta	
HP-C4913A	HP Print Cart. C4913A NO. 82	→ DnJ500/PS/800/PS	yellow	
HP-C4930A	HP Print Cart. C4930A NO. 81	→ DnJ5000/PS	black	
HP-C4931A	HP Print Cart. C4931A NO. 81	→ DnJ5000/PS	cyan	
HP-C4932A	HP Print Cart. C4932A NO. 81	→ DnJ5000/PS	magenta	
HP-C4933A	HP Print Cart. C4933A NO. 81	→ DnJ5000/PS	yellow	
HP-C4934A	HP Print Cart. C4934A NO. 81	→ DnJ5000/PS	cyan light	
HP-C4935A	HP Print Cart. C4935A NO. 81	→ DnJ5000/PS	magenta light	
HP-92274A	HP Toner Cart. 92274A	→ LaserJet 4L/4ML/4P/4MP/4LC/4JP		
HP-92275A	HP Toner Cart. 92275A	→ LaserJet IIP/Plus/IIIP		
HP-92291A	HP Toner Cart. 92291A	→ LaserJet III/IIi/45i/SiMX		
HP-92295A	HP Toner Cart. 92295A	→ LaserJet I/D/III/D		
HP-92298A	HP Toner Cart. 92298A	→ LaserJet 4/4+/4M/4M+/5/5M/5N		
HP-92298S	HP Toner Cart. 92298S	→ LaserJet 4/4+/4M/4M+/5/5M/5N	(5 x cart.)	
HP-92298X	HP Toner Cart. 92298X	→ LaserJet 4/4+/4M/4M+/5/5M/5N	high capacity	
HP-C3900A	HP Toner Cart. C3900A	→ LaserJet 4V/4MV		
HP-C3903A	HP Toner Cart. C3903A	→ LaserJet 5P/MP/6P/MP		
HP-C3906A	HP Toner Cart. C3906A	→ LaserJet 5L/6L/3100		
HP-C3909A	HP Toner Cart. C3909A	→ LaserJet 5 Si/5SiMX/5NX/5SiMopier		

**Art.Nr. ORIGINAL SUPPL. LASER & PRINTJETPRINTER**


HP-C4127A	HP Toner Cart. C4127A	→ LaserJet 4000/N/T/TN/4050/T/N/TN		
HP-C4127X	HP Toner Cart. C4127X	→ LaserJet 4000/N/T/TN/4050/T/N/TN		
HP-C4129X	HP Toner Cart. C4129X	→ LaserJet 5000		
HP-C4182X	HP Toner Cart. C4182X	→ LaserJet 8100/Mopier 320		
HP-C3105A	HP Toner Cart. C3105A	→ LaserJet/5/5M Colour	black	
HP-C3102A	HP Toner Cart. C3102A	→ LaserJet/5/5M Colour	cyan	
HP-C3103A	HP Toner Cart. C3103A	→ LaserJet/5/5M Colour	yellow	
HP-C3104A	HP Toner Cart. C3104A	→ LaserJet/5/5M Colour	magenta	
HP-C3844A	HP Toner Cart. C3844A	→ PhotoSmart star photo	mag./mag.-light/yellow	
HP-C3845A	HP Toner Cart. C3845A	→ PhotoSmart moon photo	black/cyan/cyan-light	
HP-C4092A	HP Toner Cart. C4092A	→ LaserJet 1100/A		
HP-C4096A	HP Toner Cart. C4096A	→ LaserJet 2100		
HP-C4149A	HP Toner Cart. C4149A	→ LaserJet 8500	black	
HP-C4150A	HP Toner Cart. C4150A	→ LaserJet 8500	cyan	
HP-C4151A	HP Toner Cart. C4151A	→ LaserJet 8500	magenta	
HP-C4152A	HP Toner Cart. C4152A	→ LaserJet 8500	yellow	
HP-C4191A	HP Toner Cart. C4191A	→ LaserJet 4500	black	
HP-C4192A	HP Toner Cart. C4192A	→ LaserJet 4500	cyan	
HP-C4193A	HP Toner Cart. C4193A	→ LaserJet 4500	magenta	
HP-C4194A	HP Toner Cart. C4194A	→ LaserJet 4500	yellow	
HP-C7115A	HP Toner Cart. C7115A	→ LaserJet 1200/1220		
HP-C8061A	HP Toner Cart. C8061A	→ LaserJet 4100N		
HP-C8061X	HP Toner Cart. C8061X	→ LaserJet 4100N		



**Art.Nr. ORIGINAL SUPPLIES LASER & INKJETPRINTER**


HP-C4800A	HP Printhead C4800AE NO.10	→ 2000C/CN/2500C/CM	black	
HP-C4801A	HP Printhead C4801AE NO.10	→ 2000C/CN/2500C/CM	cyan	
HP-C4802A	HP Printhead C4802AE NO.10	→ 2000C/CN/2500C/CM	magenta	
HP-C4803A	HP Printhead C4803AE NO.10	→ 2000C/CN/2500C/CM	yellow	
HP-C4820A	HP Printhead C4820A NO.80	→ DJ1050C/1055CM	black	
HP-C4821A	HP Printhead C4821A NO.80	→ DJ1050C/1055CM	cyan	
HP-C4822A	HP Printhead C4822A NO.80	→ DJ1050C/1055CM	magenta	
HP-C4823A	HP Printhead C4823A NO.80	→ DJ1050C/1055CM	yellow	
HP-C4841A	HP Print Cart. C4841AE NO.10	→ 2000C/CN/2500C/CM	cyan	(1 x 28ml)
HP-C4842A	HP Print Cart. C4842AE NO.10	→ 2000C/CN/2500C/CM	yellow	(1 x 28ml)
HP-C4843A	HP Print Cart. C4843AE NO.10	→ 2000C/CN/2500C/CM	magenta	(1 x 28ml)
HP-C4844A	HP Print Cart. C4844AE NO.10	→ 2000C/CN/2500C/CM	black	(1 x 69ml)
HP-C4871A	HP Print Cart. C4871A NO.80	→ DJ1050C/1055CM	black	(350ml)
HP-C4846A	HP Print Cart. C4846A NO.80	→ DJ1050C/1055CM	cyan	(350ml)
HP-C4847A	HP Print Cart. C4847A NO.80	→ DJ1050C/1055CM	magenta	(350ml)
HP-C4848A	HP Print Cart. C4848A NO.80	→ DJ1050C/1055CM	yellow	(350ml)
HP-C4911A	HP Print Cart. C4911A NO.82	→ DnJ500/PS/800/PS	cyan	
HP-C4912A	HP Print Cart. C4912A NO.82	→ DnJ500/PS/800/PS	magenta	
HP-C4913A	HP Print Cart. C4913A NO.82	→ DnJ500/PS/800/PS	yellow	
HP-C4930A	HP Print Cart. C4930A NO.81	→ DnJ5000/PS	black	
HP-C4931A	HP Print Cart. C4931A NO.81	→ DnJ5000/PS	cyan	
HP-C4932A	HP Print Cart. C4932A NO.81	→ DnJ5000/PS	magenta	
HP-C4933A	HP Print Cart. C4933A NO.81	→ DnJ5000/PS	yellow	
HP-C4934A	HP Print Cart. C4934A NO.81	→ DnJ5000/PS	cyan light	
HP-C4935A	HP Print Cart. C4935A NO.81	→ DnJ5000/PS	magenta light	
HP-92274A	HP Toner Cart. 92274A	→ LaserJet 4L/4ML/4P/4MP/4LC/4JP		
HP-92275A	HP Toner Cart. 92275A	→ LaserJet IIP/Plus/IIIP		
HP-92291A	HP Toner Cart. 92291A	→ LaserJet III/IIIi/4Si/5i/SiMX		
HP-92295A	HP Toner Cart. 92295A	→ LaserJet II/D/III/D		
HP-92298A	HP Toner Cart. 92298A	→ LaserJet 4/4+/4M/4M+/5/5M/5N		
HP-92298S	HP Toner Cart. 92298S	→ LaserJet 4/4+/4M/4M+/5/5M/5N		(5 x cart.)
HP-92298X	HP Toner Cart. 92298X	→ LaserJet 4/4+/4M/4M+/5/5M/5N		high capacity
HP-C3900A	HP Toner Cart. C3900A	→ LaserJet 4V/4MV		
HP-C3903A	HP Toner Cart. C3903A	→ LaserJet 5P/MP/6P/MP		
HP-C3906A	HP Toner Cart. C3906A	→ LaserJet 5L/6L/3100		
HP-C3909A	HP Toner Cart. C3909A	→ LaserJet 5 Si/5SiMX/5NX/5SiMopier		

**Art.Nr. ORIGINAL SUPPL. LASER & PRINTJETPRINTER**


HP-C4127A	HP Toner Cart. C4127A	→ LaserJet 4000/N/T/TN/4050/T/N/TN		
HP-C4127X	HP Toner Cart. C4127X	→ LaserJet 4000/N/T/TN/4050/T/N/TN		
HP-C4129X	HP Toner Cart. C4129X	→ LaserJet 5000		
HP-C4182X	HP Toner Cart. C4182X	→ LaserJet 8100/Mopier 320		
HP-C3105A	HP Toner Cart. C3105A	→ LaserJet/5/5M Colour	black	
HP-C3102A	HP Toner Cart. C3102A	→ LaserJet/5/5M Colour	cyan	
HP-C3103A	HP Toner Cart. C3103A	→ LaserJet/5/5M Colour	yellow	
HP-C3104A	HP Toner Cart. C3104A	→ LaserJet/5/5M Colour	magenta	
HP-C3844A	HP Toner Cart. C3844A	→ PhotoSmart star photo	mag/mag.-light/yellow	
HP-C3845A	HP Toner Cart. C3845A	→ PhotoSmart moon photo	black/cyan/cyan-light	
HP-C4092A	HP Toner Cart. C4092A	→ LaserJet 1100/A		
HP-C4096A	HP Toner Cart. C4096A	→ LaserJet 2100		
HP-C4149A	HP Toner Cart. C4149A	→ LaserJet 8500	black	
HP-C4150A	HP Toner Cart. C4150A	→ LaserJet 8500	cyan	
HP-C4151A	HP Toner Cart. C4151A	→ LaserJet 8500	magenta	
HP-C4152A	HP Toner Cart. C4152A	→ LaserJet 8500	yellow	
HP-C4191A	HP Toner Cart. C4191A	→ LaserJet 4500	black	
HP-C4192A	HP Toner Cart. C4192A	→ LaserJet 4500	cyan	
HP-C4193A	HP Toner Cart. C4193A	→ LaserJet 4500	magenta	
HP-C4194A	HP Toner Cart. C4194A	→ LaserJet 4500	yellow	
HP-C7115A	HP Toner Cart. C7115A	→ LaserJet 1200/1220		
HP-C8061A	HP Toner Cart. C8061A	→ LaserJet 4100N		
HP-C8061X	HP Toner Cart. C8061X	→ LaserJet 4100N		

