

ART.Nr. ORIGINAL SUPPLIES PRINTER & FAX

OKI

OKIT1400	OKI Toner OL400/410/800/8110/830/840/850/OF2300	(09002392)
OKIT1400E	OKI Toner OL400E/410E/800E/8110E/830E/840E/850E/OF2300E OF1000/1050/2200/2350/2400/502/600/5200/5400/5500	(09002395)
OKIT1200E	OKI Toner OL1200E/OP16n	(09002386)
OKIT110I	OKI Toner OKIPAGE 10/6x/12/14	(40433203)
OKIT14I	OKI Toner OKIPAGE 14/6x/16	(41331702)
OKIT20N	OKI Toner OKIPAGE 20/n/4/24DX	(40468802)
OKIT4W	OKI Toner OKIPAGE 4n/4w/4w+/OF4100	(09002390)
OKIT8W	OKI Toner OKIPAGE 8w/8p/8w+/OF4500/4550	(00079801)
OKIT120	OKI Toner OF120	(09002701)
OKIT5700	OKI Toner OF5700/5750/5900/5950	(40815604)
OKIT8CBK	OKI Toner OKIPAGE 8c +	black (41012305)
OKIT8C	OKI Toner OKIPAGE 8c +	cyan (41012308)
OKIT8CM	OKI Toner OKIPAGE 8c +	magenta (41012307)
OKIT8CY	OKI Toner OKIPAGE 8c +	yellow (41012306)
OKIT7000BK	OKI Toner OKIPAGE C7000/7200/n/dn/7400	black (41304212)
OKIT7000C	OKI Toner OKIPAGE C7000/7200/n/dn/7400	cyan (41304211)
OKIT7000M	OKI Toner OKIPAGE C7000/7200/n/dn/7400	magenta (41304210)
OKIT7000Y	OKI Toner OKIPAGE C7000/7200/n/dn/7400	yellow (41304209)
OKIT9200BK	OKI Toner OKIPAGE C9200/n/dn/9400	black (41515212)
OKIT9200C	OKI Toner OKIPAGE C9200/n/dn/9400	cyan (41515211)
OKIT9200M	OKI Toner OKIPAGE C9200/n/dn/9400	magenta (41515210)
OKIT9200Y	OKI Toner OKIPAGE C9200/n/dn/9400	yellow (41515209)
OKITR400E	OKI Drum OL400/410/800/8110/830/840/850/OF2300 OF1000/1050/2200/2350/2400/2450/2600/5200/5400/5500	(09001039) (09001042)
OKITR1200E	OKI Drum OL1200E/OP16n	(09001045)
OKITR10I	OKI Drum OKIPAGE 10/6x/12/14/OF5700/5750/5900/5950 Type 5	(40433303)
OKITR14I	OKI Drum OKIPAGE 14/6x/16	(41331602)
OKITR20N	OKI Drum OKIPAGE 20/n/4/24DX Type 7	(40468702)
OKITR4W	OKI Drum OKIPAGE 4n/4w/4w+/OF4100	(09001038)
OKITR8W	OKI Drum OKIPAGE 8w/8p/8w+/OF4500/4550	(40709902)
OKITR8CBK	OKI Drum OKIPAGE 8c + Type C1	black (41070205)
OKITR8C	OKI Drum OKIPAGE 8c + Type C1	cyan (41070208)
OKITR8CM	OKI Drum OKIPAGE 8c + Type C1	magenta (41070207)
OKITR8CY	OKI Drum OKIPAGE 8c + Type C1	yellow (41070206)
OKITR7000B	OKI Drum OKIPAGE C7000/7200/n/dn/7400	black (41304112)
OKITR7000C	OKI Drum OKIPAGE C7000/7200/n/dn/7400	cyan (41304111)
OKITR7000M	OKI Drum OKIPAGE C7000/7200/n/dn/7400	magenta (41304110)
OKITR7000Y	OKI Drum OKIPAGE C7000/7200/n/dn/7400	yellow (41304109)

ART.Nr. ORIGINAL SUPPLIES PRINTER & FAX

OKI

OKITR9200B	OKI Drum OKIPAGE C9200/n/dn/9400	black (41514712)
OKITR9200C	OKI Drum OKIPAGE C9200/n/dn/9400	cyan (41514711)
OKITR9200M	OKI Drum OKIPAGE C9200/n/dn/9400	magenta (41514710)
OKITR9200Y	OKI Drum OKIPAGE C9200/n/dn/9400	yellow (41514709)
OKITR120	OKI Drum OF120	(09002700)
OKIT1300BK	OKI Ink Cart. OJ300/2010/OF740/MF (Monoblock)	black (09001309)
OKIT1300C	OKI Ink Cart. OJ300/2010/OF740/MF (Monoblock)	cyan (09001308)
OKIT1300M	OKI Ink Cart. OF510 (Monoblock)	black (09002794)
OKIT1300Y	OKI Ink Cart. OF510 (Monoblock)	black (09002838)
OKIT610	OKI Ink Film OF610/660 (2 Rolls)	(09002691)
OKIF182	OKI Ribbon ML 182/280/320/321/332/0/3321	black (09002303)
OKIF292	OKI Ribbon ML 292	black (09002304)
OKIF292C	OKI Ribbon ML 292	colour (09002305)
OKIF293BK	OKI Ribbon ML 293/294	black (09002306)
OKIF293C	OKI Ribbon ML 293/294	colour (09002307)
OKIF390	OKI Ribbon ML 380/385/390/1/3390/3391	black (09002309)
OKIF390FB	OKI Ribbon ML 320/390 Flatbed	black (09002310)
OKIF393	OKI Ribbon ML 393/395	black (09002311)
OKIF393C	OKI Ribbon ML 393/395	colour (09002312)
OKIF520	OKI Ribbon ML 520/521	black (09002315)
OKIF590	OKI Ribbon ML 590/591	black (09002316)
OKIF590C	OKI Ribbon ML 590/591	colour (40107101)
OKIF4410	OKI Ribbon ML 4410	black (09002308)
OKIF4410	OKI Ribbon ML 4410	black (40629303)

OKI

