

Art.Nr.	ORIGINAL TONER COPIER	Panasonic
PANT1270	Panasonic Toner FQ-TC10 → FP-1270/1275/1370	(1 x 50g)
PANT1530	Panasonic Toner FQ-T50K-PG → FP-1307/1510/30/40	(1 x 190g)
PANT1570	Panasonic Toner FQ-T80R → FP-1570	(1 x 180g)
PANT1670	Panasonic Toner FQ-TA10 → FP-1670/1620/1780	(1 x 290g)
PANT2670	Panasonic Toner FQ-TA20 → FP-2670/80/3270/3380/7127/7133	(1 x 500g)
PANT3030	Panasonic Toner FQ-T30H → FP-3007/30/37/40/4630/50/5060	(1 x 420g)
PANT4080	Panasonic Toner FQ-TA30 → FP-4080/7140	(1 x 500g)
PANT6070	Panasonic Toner FQ-T65V → FP-6070	(1 x 670g)
PANT7115	Panasonic Toner FQ-TF15 → FP-7113/7115/7713/7715	(1 x 185g)
PANT7117	Panasonic Toner FQ-TA19 → FP-7117/7121/1680/2080	(1 x 290g)
PANT7160	Panasonic Toner FQ-TE60 → FP-7160	
PANT7718	Panasonic Toner FQ-TK10 → FP-7718/7722/7818/7824	(1 x 462g)
PANT7728	Panasonic Toner FQ-TK20 → FP-7728/35/42/50/7830/35/45/50	(1 x 660g)
PANT7760	Panasonic Toner FQ-TE70 → FP-7760/7781	
PANT820	Panasonic Toner FQ-U160 → FP-820/830	
PANT250	Panasonic Toner FQ-TL20 → FP-D250/350/355	
PANT600	Panasonic Toner FQ-TL24 → FP-D450/455/600	
PANTDP150	Panasonic Toner Cart. DQ-UG15 → DP150/A/P/FP	
PANT188	Panasonic Toner Cart. DQ-TU188 → DP2000/2500/D	

Art.Nr.	ORIGINAL DEVELOPER COPIER	Panasonic
PAND1307	Panasonic Dev. FQ-Z120-PG → FP-1307/1510/1530/1540	(1 x 50g)
PAND1570	Panasonic Dev. FQ-Z170 → FP-1570	(1 x 350g)
PAND4080	Panasonic Dev. FQ-ZA30 → FP-4080	(1 x 950g)
PAND6070	Panasonic Dev. FQ-Z190 → FP-6070	
PAND7115	Panasonic Dev. FQ-ZF15 → FP-7113/7115/7713/7715	(1 x 630g)
PAND7117	Panasonic Dev. FQ-ZA25 → FP-1620/70/80/1780/2670/80/3270/3380/7117/21/27/33	(1 x 950g)
PAND7160	Panasonic Dev. FQ-ZE60 → FP-7160/7760/7781	
PAND7718	Panasonic Dev. FQ-ZK10 → FP-7718/7722/7818/7824	(1 x 650g)
PAND7728	Panasonic Dev. FQ-ZK20 → FP-7728/35/42/50/7830/50	(1 x 750g)
PANDD250	Panasonic Dev. FQ-ZL20 → FP-D250/350/355	
PANDD450	Panasonic Dev. FQ-ZL30 → FP-D450/455/600	

Art.Nr.	ORIGINAL DRUMS COPIER	Panasonic
PANTR1270	Panasonic Drum FQ-M210 → FP-1270/1275/1370	Developer
PANTR1670	Panasonic Drum FQ-HA10 → FP-1620/70/80/1780/2080/2670/80/3270/3380/7117/21/27/33	
PANTR4080	Panasonic Drum FQ-HA30 → FP-4080/7140	
PANTR6070	Panasonic Drum FQ-H770 → FP-6070	
PANTR7113	Panasonic Drum FQ-HF13 → FP-7113/7115/7713/7715	
PANTR7718	Panasonic Drum FQ-HK10 → FP-7718/7722/7728/7735/7818/7824	
PANTR7742	Panasonic Drum FQ-HK20 → FP-7742/7750/7830/7835/7845/7850	
PANTR7760	Panasonic Drum FQ-HE70 → FP-7760/7781	
PANTRD250	Panasonic Drum FQ-HL20 → FP-D250/335/350/450/455/600	
PANTRDP150	Panasonic Drum DQ-UG32 → DP150/A/P/FP	
PANT188	Panasonic Drum DQ-HO308 → DP2000/2500/D	



Panas

Art.Nr. ORIGINAL SUPPLIES FAX/LASER & INKJETPRINTER Panasonic

PANT3202	Panasonic Toner Kit UG-3202	→ UF-733	
PANTR3302	Panasonic Proc. UG-3302	→ UF-733	UNIT
PANT3204	Panasonic Toner Cart. UG-3204	→ UF-745/755	
PANT3309	Panasonic Toner Cart. UG-3309	→ UF-744/788	
PANT3313	Panasonic Toner Cart. UG-3313	→ UF-550/560/770/880/85/95/DX-1000/DF-1100	
PANT3350	Panasonic Toner Cart. UG-3350	→ UF-585/595	
PANT75X	Panasonic Toner Cart. KX-FA75X	→ KX-FLM600	
PANT76X	Panasonic Toner Cart. KX-FA76X	→ KX-FL501	
PANTR77X	Panasonic Drum KX-FA77X	→ KX-FL501	
PANF132	Panasonic Print. Cart. KX-FA132X	→ KX-F1000	
PANF133	Panasonic Refill Rolls KX-FA133X	→ KX-F1000	
PANF135	Panasonic Film Cart. KX-FA135X	→ KX-F1810/30/FP-300/20/FM-30 (1 x 100m Roll)	
PANF136	Panasonic Refill Film KX-FA136X	→ KX-F1810/20/30/FP-300/20/FM-330 (2 x 100m Rolls)	
PANT450	Panasonic Toner Kit KX-P450i	→ KX-P4450/50i/51/55	
PANT451	Panasonic Toner Kit KX-P451	→ KX-P4420	
PANT453	Panasonic Toner Kit KX-P453	→ KX-P4410/30/40/5410/UF-766	
PANT455	Panasonic Toner Kit KX-P455	→ KX-P4400/5400/KX-F3000	
PANT457	Panasonic Toner Cart. KX-P457	→ KX-P6100/6150	
PANT459	Panasonic Toner Cart. KX-P459	→ KX-P6500/6300/PS600	
PANDPDP1	Panasonic Dev. KX-PDP1	→ KX-P4450/50i/51/55	
PANDPDP2	Panasonic Dev. KX-PDP2	→ KX-P4420	
PANDPDP5	Panasonic Dev. KX-PDP5	→ KX-P4410/30/5410/UF-766	
PANTRPDM1	Panasonic Drum KX-PDM1	→ KX-P4450/50i/51/55	
PANTRPDM2	Panasonic Drum KX-PDM2	→ KX-P4420	
PANTRPDM5	Panasonic Drum KX-PDM5	→ KX-P4410/30/40/5410/UF-766	
PANTRPDM6	Panasonic Drum KX-PDM6	→ KX-P4400/5400	
PANTRPEP3	Panasonic Proc. KX-PEP3	→ KX-P6100/6150	UNIT
PANTRPEP5	Panasonic Proc. KX-PEP5	→ KX-P6500	UNIT
PANTRPEP6	Panasonic Proc. KX-PEP6	→ KX-P7200	UNIT
PANTRPEP8	Panasonic Proc. KX-PEP8	→ KX-P7510	UNIT
PANDPFS1	Panasonic Fixier Station KX-PF51	→ KX-P4450/50i/51/55	
PANDPFS2	Panasonic Fixier Station KX-PF52	→ KX-P4420	
PANDPFS5	Panasonic Fixier Station KX-PF55	→ KX-P4410/30/5410/UF-766	
PANDPFS6	Panasonic Fixier Station KX-PF56	→ KX-P4440	
PANPC20BK	Panasonic Print Cart. PC-20BK	→ UF-E1	black
PANPC20CL	Panasonic Print Cart. PC-20CL	→ UF-E1	colour
PANPC60BK	Panasonic Print Cart. PC-60BK	→ UF-300/511/12/15/21/22/32/33	black
PANT3502B	Panasonic Print Cart. UG-3502B	→ UF-342/344	black

Art.Nr. ORIGINAL SUPPLIES FAX/LASER & INKJETPRINTER Panasonic

PANTPDPK4	Panasonic Toner Cart. KX-PDPK4	→ KX-PS8000 black	
PANTPDPC4	Panasonic Toner Cart. KX-PDPC4	→ KX-PS8000 cyan	
PANTPDPM4	Panasonic Toner Cart. KX-PDPM4	→ KX-PS8000 magenta	
PANTPDPY4	Panasonic Toner Cart. KX-PDPY4	→ KX-PS8000 yellow	
PANTPDPK6	Panasonic Toner Cart. KX-PDPK6	→ KX-P8410/20 black	
PANTPDPC6	Panasonic Toner Cart. KX-PDPC6	→ KX-P8410/20 cyan	
PANTPDPM6	Panasonic Toner Cart. KX-PDPM6	→ KX-P8410/20 magenta	
PANTPDPY6	Panasonic Toner Cart. KX-PDPY6	→ KX-P8410/20 yellow	
PANTPDPK8	Panasonic Toner Cart. KX-PDPK8	→ KX-P8415 black	
PANTPDPC8	Panasonic Toner Cart. KX-PDPC8	→ KX-P8415 cyan	
PANTPDPM8	Panasonic Toner Cart. KX-PDPM8	→ KX-P8415 magenta	
PANTPDPY8	Panasonic Toner Cart. KX-PDPY8	→ KX-P8415 yellow	
PANF115	Panasonic Ribbon KX-P115i	→ KX-P1080/1/2/3	
PANF145	Panasonic Ribbon KX-P145	→ KX-P1123/24/i/2023	
PANF150	Panasonic Ribbon KX-P150	→ KX-P2123/24/80 black	
PANF150C	Panasonic Ribbon KX-P150C	→ KX-P2123/24/80 4-colours	
PANF155	Panasonic Ribbon KX-P155	→ KX-P1624/54/2624	
PANF170	Panasonic Ribbon KX-P170	→ KP-P3696 longlife	


