

| Art.Nr. | ORIGINAL TONER COPIER | TOSHIBA | | |
|---------|-----------------------|---------|--|--|
|---------|-----------------------|---------|--|--|

| | | | | |
|-----------|---------------------------|---------------------------------|-------------|-------------|
| TOST61P | Toshiba Toner T-61P | → 3110 | (1 x 110g) | (2231099) |
| TOST64P | Toshiba Toner T-64P | → 5110/20/5610/20/ 7610/7720 | (1 x 265g) | (2230120) |
| TOST66P | Toshiba Toner T-66P | → 4810 | (1 x 250g) | (2230133) |
| TOST68P | Toshiba Toner T-68P | → 9100/10/9230/40 | (1 x 275g) | (66084753) |
| TOST80P | Toshiba Toner T-80P | → 5110/20/5610/20/ 7610/7720 | (1 x 265g) | (2230152) |
| TOST85PE | Toshiba Toner T-85PE | → 1310/3810/3910 | (1 x 200g) | (66084755) |
| TOST88P | Toshiba Toner T-88P | → 8505/10 | (1 x 350g) | (2231003) |
| TOST120PE | Toshiba Toner T-120PE | → 1210/2810 | (1 x 145g) | (66084757) |
| TOST220P | Toshiba Toner T-220P | → 2230/4910/5910/7910 | (1 x 375g) | (2231064) |
| TOST1350E | Toshiba Toner T-1350E | → 1340/50/60/70 | (1 x 180g) | (66084567) |
| TOST1550E | Toshiba Toner T-1550E | → 1550 | (1 x 240g) | (66062039) |
| TOST1570E | Toshiba Toner T-1570E | → 1570 | | (66089272) |
| TOST1600E | Toshiba Toner T-1600E | → 1600 | (1 x 335g) | (66061614) |
| TOST1710E | Toshiba Toner T-1710E | → 1710/2310/2500 | (1 x 300g) | (66062020) |
| TOST2050E | Toshiba Toner T-2050E | → 1650/2050/2540 | (1 x 300g) | (66062005) |
| TOST2060E | Toshiba Toner T-2060E | → 2060/2860/70 | (1 x 300g) | (66062042) |
| TOST2460E | Toshiba Toner T-2460E | → 2460/2570 | (1 x 300g) | (66061598) |
| TOST2510E | Toshiba Toner T-2510E | → 2510/2550 | (1 x 450g) | (66062023) |
| TOST3210E | Toshiba Toner T-3210E | → 3210 | (1 x 420g) | (2231204) |
| TOST3240E | Toshiba Toner T-3240E | → 3240 | (1 x 420g) | (66062017) |
| TOST3560E | Toshiba Toner T-3560E | → 3560/4560 | (1 x 500g) | (66062048) |
| TOST3580E | Toshiba Toner T-3580E | → 3580 | (1 x 300g) | (66089338) |
| TOST3850E | Toshiba Toner T-3850E | → 3850 | (1 x 500g) | (66084731) |
| TOST4010E | Toshiba Toner T-4010E | → 3220/4010 | (1 x 450g) | (66062025) |
| TOST4550E | Toshiba Toner T-4550E | → 3550/4550 | (1 x 550g) | (66062007) |
| TOST5020E | Toshiba Toner T-5020E | → 5010/5020 | (1 x 550g) | (66084759) |
| TOST6550E | Toshiba Toner T-6550E | → 5540/6550 | (1 x 1200g) | (2231225) |
| TOST6560E | Toshiba Toner T-6560E | → 5560/6560 | (1 x 1350g) | (66062044) |
| TOST6570E | Toshiba Toner T-6570E | → 5570/6570 | | (66089380) |
| TOST7650E | Toshiba Toner T-7650E | → 7650/60 | (1 x 1350g) | (66061589) |
| TOST8050E | Toshiba Toner T-8050E | → 8050 | (1 x 1500g) | (66084613) |
| TOST9050N | Toshiba Toner T-9050N | → 9050/9260 | (1 x 1040g) | (66089240) |
| TOST1450E | Toshiba Imag. OS-1450E | → 1250/1450 | UNIT | (113R00335) |
| TOST22BK | Toshiba Toner PS-ZTFC22EK | → TF15/22/25P | black | (66089503) |
| TOST22C | Toshiba Toner PS-ZTFC22EC | → TF15/22/25P | cyan | (66089506) |
| TOST22M | Toshiba Toner PS-ZTFC22EM | → TF15/22/25P | Magenta | (66089505) |
| TOST22Y | Toshiba Toner PS-ZTFC22EY | → TF15/22/25P | yellow | (66089504) |

| Art.Nr. | ORIGINAL DEVELOPER COPIER | TOSHIBA | | |
|---------|---------------------------|---------|--|--|
|---------|---------------------------|---------|--|--|

| | | | | |
|----------|-----------------------------|---|-------------|--------------|
| TOSD58P | Toshiba Developer D-58P-75 | → 5110/20/5910/7610/7720/8412 | | (4409840850) |
| TOSD68P | Toshiba Developer D-68P-130 | → 9100/10/9230/40 | (1 x 1300g) | (4409843380) |
| TOSD85P | Toshiba Developer D-85P-47 | → 1310/3810/3910 | (1 x 470g) | (4409843450) |
| TOSD88P | Toshiba Developer D-88P-75 | → 8510 | | (2231004) |
| TOSD220P | Toshiba Developer D-220P-75 | → 4910/7910 | | (2231067) |
| TOSD1210 | Toshiba Developer D-1210 | → 1210/2810 | (1 x 420g) | (4409843430) |
| TOSD1350 | Toshiba Developer D-1350 | → 1340/50/60/70 | (1 x 430g) | (4409843650) |
| TOSD1550 | Toshiba Developer D-1550 | → 1550 | (1 x 670g) | (4409847480) |
| TOSD1710 | Toshiba Developer D-1710P | → 1650/1710/2050/ 2310/2500/10/40/50/3210/20/40/4010 | (1 x 650g) | (4409843510) |
| TOSD2060 | Toshiba Developer D-2060 | → 2060/2860 | | (4409850730) |
| TOSD2460 | Toshiba Developer D-2460 | → 2460/2570 | | (4409853780) |
| TOSD3560 | Toshiba Developer D-3560 | → 3560 | | (4409855350) |
| TOSD3580 | Toshiba Developer D-3580 | → 3580 | | (4409859710) |
| TOSD3850 | Toshiba Developer D-3850 | → 3850 | | (4409841010) |
| TOSD4550 | Toshiba Developer D-4550 | → 3550/4550 | (1x650g) | (4409843670) |
| TOSD4560 | Toshiba Developer D-4560 | → 4560 | | (4409855730) |
| TOSD5020 | Toshiba Developer D-5020 | → 5010/20 | | (4409843580) |
| TOSD6550 | Toshiba Developer D-6550 | → 5540/6550 | (1x1200g) | (4409843640) |
| TOSD6560 | Toshiba Developer D-6560 | → 5560/6560 | | (4409850810) |
| TOSD7550 | Toshiba Developer D-7550 | → 7650/7660 | (1x1300g) | (4409847050) |
| TOSD6570 | Toshiba Developer D-6570 | → 5570/6570 | | (4409863570) |
| TOSD8050 | Toshiba Developer D-8050 | → 8050 | | (66084615) |
| TOSD9050 | Toshiba Developer D-9050 | → 9050/9260 | | (66089034) |
| TOSD22BK | Toshiba Developer D-FC22K | → TF15/22/25P | black | (440987390) |
| TOSD22C | Toshiba Developer D-FC22C | → TF15/22/25P | cyan | (4409873480) |
| TOSD22M | Toshiba Developer D-FC22M | → TF15/22/25P | magenta | (4409873450) |
| TOSD22Y | Toshiba Developer D-FC22Y | → TF15/22/25P | yellow | (4409873420) |

TOSHIBA



| Art.Nr. | ORIGINAL DRUMS COPIER | TOSHIBA |
|------------|---|--------------|
| TOSTR61M | Toshiba Selen Drum SD-61-M → 1310/3810/3910 | (4409987050) |
| TOSTR83L | Toshiba Selen Drum SD-83-L → 4810/5610/20/8412 | (4409946320) |
| TOSTR86L | Toshiba Selen Drum SD-86-L → 4910/5110/20/5910/ 7610/7720/7910 | (2230129) |
| TOSTR87L | Toshiba Selen Drum SD-87-L → 5010/20/9100/10/9230/40 | (2230142) |
| TOSTR88L | Toshiba Selen Drum SD-88-L → 8510 | |
| TOSTR5540 | Toshiba Selen Drum SD-5540 → 5540 | (4409834920) |
| TOSTR6550 | Toshiba Selen Drum SD-6550 → 6550 | (2231223) |
| TOSTR6570 | Toshiba Selen Drum OD-6570 → 5570/6570 | (4409892640) |
| TOSTR7550 | Toshiba Selen Drum SD-7550 → 7650/60 | (4409845540) |
| TOSTR8050 | Toshiba Selen Drum SD-8050 → 8050 | (A0849510) |
| TOSTR9050 | Toshiba Selen Drum SD-9050 → 9050/9260 | (66089035) |
| TOSTR1210 | Toshiba OPC Drum OD-1210 → 1210/2810 | (4409824560) |
| TOSTR1350 | Toshiba OPC Drum OD-1350 → 1340/50/60/70 | (4409832520) |
| TOSTR1550 | Toshiba OPC Drum OD-1550 → 1550 | (4409847360) |
| TOSTR1710 | Toshiba OPC Drum OD-1710 → 1650/1710/2050/2310/2500/40 | (4409891800) |
| TOSTR2060 | Toshiba OPC Drum OD-2060 → 2060/2860 | (4409890370) |
| TOSTR2460 | Toshiba OPC Drum OD-2460 → 2460/2570 | (4409890890) |
| TOSTR2510 | Toshiba OPC Drum OD-2510 → 2510/50 | (4409891820) |
| TOSTR3210 | Toshiba OPC Drum OD-3210 → 3210/40 | (4409891810) |
| TOSTR3560 | Toshiba OPC Drum OD-3560 → 3560 | (4409891360) |
| TOSTR3850 | Toshiba OPC Drum OD-3850 → 3850 | (4409840010) |
| TOSTR4010 | Toshiba OPC Drum OD-4010 → 3220/3550/4010 | (4409891830) |
| TOSTR4550 | Toshiba OPC Drum OD-4550 → 4550 | (4409891840) |
| TOSTR4560 | Toshiba OPC Drum OD-4560 → 4560 | (4409891450) |
| TOSTR6560 | Toshiba OPC Drum OD-6560 → 5560/6560 | (4409890390) |
| TOSTR22 | Toshiba OPC Drum OD-FC22 → TF15/22/25P | (4409893070) |
| TOSTR1570E | Toshiba Imag. OS-1570 → 1570 UNIT | (66089274) |



| Art.Nr. | ORIGINAL TONERBAGS | TOSHIBA |
|-----------|--|------------|
| TOSTB300 | Toshiba Tonerbag TB-300 → 3110 | (2230078) |
| TOSTB310 | Toshiba Tonerbag TB-310 → 1310/3810/3910 | (2231027) |
| TOSTB320 | Toshiba Tonerbag TB-320 → 1210/2810 | (2231022) |
| TOSTB420 | Toshiba Tonerbag TB-420 → 4810/4910/5110/20/5610/ 20/5910/7610/7720/7910/8510 | (2231005) |
| TOSTB500 | Toshiba Tonerbag TB-500 → 9100/10 | (2230145) |
| TOSTB510 | Toshiba Tonerbag TB-510 → 9230/40 | (2231060) |
| TOSTB1350 | Toshiba Tonerbag TB-1350 → 1340/50/60/70 | (66084576) |
| TOSTB1550 | Toshiba Tonerbag TB-1550E → 1550 | (66084860) |
| TOSTB1570 | Toshiba Tonerbag TB-1570E → 1570 | (66089278) |
| TOSTB1710 | Toshiba Tonerbag TB-1710-BA → 1650/1710/2050/2310/2500/40/3210/40 | (2231135) |
| TOSTB2060 | Toshiba Tonerbag TB-2060E → 2060/2860/3560/4560 | (66089010) |
| TOSTB2460 | Toshiba Tonerbag TB-2460E → 2460/3580 | (66089164) |
| TOSTB2510 | Toshiba Tonerbag TB-2510-BA → 2510/50/3220/3550/4010/4550/5010/20 | (2231120) |
| TOSTB3850 | Toshiba Tonerbag TB-3850 → 3850 | (66084897) |
| TOSTB6550 | Toshiba Tonerbag TB-6550E → 5540/60/6550/60/7650/60 | (2231227) |
| TOSTB22 | Toshiba Tonerbag PS-TBFC22E → TF15/22/25P | (66089508) |

| Art.Nr. | ORIGINAL SUPPLIES FAX | TOSHIBA |
|-----------|---|------------|
| TOSTIF01 | Toshiba Ink Film IF-01 → TF511 (2 Rolls) | (1410762) |
| TOSTIF02 | Toshiba Ink Film IF-02 → TFP91 (3 Paper + 3 Rolls) | (1500100) |
| TOSTIF03 | Toshiba Ink Film IF-03 → TFP100/471 (3 Rolls) | (1500150) |
| TOSTTK01 | Toshiba Toner Kit TK-01 → TF541/561/581/5 | (1462031) |
| TOSTTK05 | Toshiba Toner Kit TK-05 → TF521/531/551/651/831/851/861 | (21203945) |
| TOSTTK10 | Toshiba Toner Kit TK-10 → TF631 | (22569346) |
| TOSTTK12 | Toshiba Toner Kit TK-12 → TF501/505/601/605/610 (2 Toner) | (22569372) |
| TOSTTK15 | Toshiba Toner TK-15 → DP120 | (21204094) |
| TOSTTK18 | Toshiba Toner TK-18 → DP80/85 | (21204099) |
| TOSTRDK01 | Toshiba Drum Unit DK01 → TF541/561/581 | (1462032) |
| TOSTRDK10 | Toshiba Drum Unit DK10 → TF631 | (22569345) |
| TOSTRDK15 | Toshiba Drum Unit DK15 → DP120 | (21204095) |
| TOSTRDK18 | Toshiba Drum Unit DK18 → DP80/85 | (21204095) |
| TOSTRPK01 | Toshiba Drum Unit PK015 → TF531/551 | (21203964) |
| TOSTRPK04 | Toshiba Drum Unit PK04 → F521/651/831/851/861 | (21203946) |
| TOSTRPK12 | Toshiba Drum Unit PK12 → TF501/505/601/605/610 | (21204039) |