

Art.Nr.	ORIGINAL TONER COPIER	XEROX	
XERT1025	Xerox Toner 1025/38/5025/26/5331/32	(1 x 227g)	(006R90099)
XERT1050	Xerox Toner 1050/5051/52/53	(1 x 550g)	(006R90094)
XERT1055	Xerox Toner 1055	(1 x 530g)	(006R90138)
XERT1065	Xerox Toner 1065/5065/5365	(1 x 680g)	(006R90147)
XERT1090	Xerox Toner 1075/1090/4050/90/4650/5088/4450	(1 x 1360g)	(006R00303)
XERT2510	Xerox Toner 2510/2511	(1 x 680g)	(006R90129)
XERT2515	Xerox Toner 2515/2520	(1 x 680g)	(006R90166)
XERT3030	Xerox Toner 3030/50/60	(1 x 680g)	(006R90269)
XERT3080	Xerox Toner 3080		(006R90130)
XERT3090	Xerox Toner 3090		(006R90210)
XERT4010	Xerox Toner 4010/4011	(2 x 250g)	(006R90233)
XERT4030	Xerox Toner 3010/4030/4197/6522	(1 x 500g)	(006R00282)
XERT4045	Xerox Toner 4045/46	(1 x 230g)	(006R90124)
XERT4060	Xerox Toner 4047/60/75	(1 x 900g)	(006R90215)
XERT4220	Xerox Toner 4220/22/30	(2 x Toner)	(006R00348)
XERT5007	Xerox Toner 5007	(1 x 50g)	(006R90157)
XERT5009	Xerox Toner 5009/R/520R/5309/10		(006R90170)
XERT5012	Xerox Toner 1012/5012/14	(1 x 400g)	(006R90161)
XERT5012	Xerox Toner 1012/5012/14	(1 x 400g)	(006R90161)
XERT5017	Xerox Toner 5017/5317	(1 x 400g)	(006R90168)
XERT5018	Xerox Toner 5018/28/34/5321/28/34/5824/26/28/30	(1 x 575g)	(006R90127)
XERT5046	Xerox Toner 5046/47/4235/DC535	(1 x 700g)	(006R90098)
XERT5046	Xerox Toner 5046/47/4235/DC535	(1 x 700g)	(006R90098)
XERT5080	Xerox Toner 5080	(3 x 400g)	(006R90162)
XERT5090	Xerox Toner 4135/4635/5090/5390/5690/ 6135/DCT135/DCP96/180	(1 x 3170g)	(006R90100)
XERT5100	Xerox Toner 5100/5800	(1 x 2270g)	(006R90159)
XERT5220	Xerox Toner 5205/10/20/22/XC520/40/60/80		(006R00589)
XERT5305	Xerox Toner 5201/03/5305/5113/XC351/55/56		(006R90224)
XERT5312	Xerox Toner 5312/14	(1 x 380g)	(006R90177)
XERT5320	Xerox Toner 5320/22/5622	(1 x 460g)	(006R90182)
XERT5340	Xerox Toner 5340/43/50/52/5437/51/5665/5837/45/55	(1 x 700g)	(006R90203)
XERT5345	Xerox Toner 5345/55/5435		(006R90209)
XERT5614	Xerox Toner 5614	(1 x 237g)	(006R90223)
XERT5621	Xerox Toner 5616/21/5815	(4 x 227g)	(006R90270)
XERT8808	Xerox Printcartridge 8808		(013R00534)
XERT8810	Xerox Printcartridge 8810/8812		(013R90106)
XERT8830	Xerox Toner 8830		(006R90268)
XERT8836	Xerox Toner 8836/8888		(006R00239)
XERTXC23	Xerox Toner Cart. XC23		(006R00910)
XERTXE60	Xerox Toner Cart. XE60/62/80/82/84		(006R00917)
XERTXD104	Xerox Toner Cart. XD100/102/103/104/120f/155df		(006R00914)
XERTXC810	Xerox Toner Cart. XC810/11/20/22/30/55/75/ XC1020/33/40/44/45/1245/55		(006R00890)

Art.Nr.	ORIGINAL TONER COPIER	XEROX	
XERT4200BL	Xerox Toner 4700/5775 black		(006R90198)
XERT4700C	Xerox Toner 4700/5775 cyan		(006R90199)
XERT4700M	Xerox Toner 4700/5775 magenta		(006R90201)
XERT4700Y	Xerox Toner 4700/5775 yellow		(006R90200)
XERT4850BK	Xerox Toner 4850/90/DP350/90 black		(006R90193)
XERT4850C	Xerox Toner 4850/90 cyan		(006R90225)
XERT4850GR	Xerox Toner 4850/90 green		(006R90196)
XERT4850M	Xerox Toner 4850/90 magenta		(006R90227)
XERTS380BK	Xerox Toner 5380/82/85	(4 x 760g)	(006R90234)
XERTS380BR	Xerox Toner 5380/5382/5385 brown	(3 x Toner)	(006R90191)
XERTS380FA	Xerox Toner 5380/5382/5385 blue	(3 x Toner)	(006R90192)
XERTS380GR	Xerox Toner 5380/5382/5385 green	(3 x Toner)	(006R90190)
XERTS380RO	Xerox Toner 5380/5382/5385 red	(3 x Toner)	(006R90189)
XERTS750BK	Xerox Toner 5750 black	(2 x Toner)	(006R90260)
XERTS750C	Xerox Toner 5750 cyan	(2 x Toner)	(006R90261)
XERTS750M	Xerox Toner 5750 magenta	(2 x Toner)	(006R90262)
XERTS750Y	Xerox Toner 5750 yellow	(2 x Toner)	(006R90263)
XERTS760BK	Xerox Toner 5760/65/5790/99 black		(006R90211)
XERTS760C	Xerox Toner 5760/65/5790/99 cyan	(1 x 300g)	(006R90212)
XERTS760M	Xerox Toner 5760/65/5790/99 magenta	(1 x 300g)	(006R90214)
XERTS760Y	Xerox Toner 5760/65/5790/99 yellow	(1 x 300g)	(006R90213)
XERTDC12BK	Xerox Toner DC12/DCC550 black		(006R90280)
XERTDC12C	Xerox Toner DC12/DCC550 cyan		(006R90281)
XERTDC12M	Xerox Toner DC12/DCC550 magenta		(006R90282)
XERTDC12Y	Xerox Toner DC12/DCC550 yellow		(006R90283)
XERTDC40BL	Xerox Toner DC40 black		(006R90247)
XERTDC40CY	Xerox Toner DC40 cyan		(006R90250)
XERTDC40MA	Xerox Toner DC40 magenta		(006R90249)
XERTDC40YE	Xerox Toner DC40 yellow		(006R90248)



XEROX

Art.Nr. ORIGINAL DRUMS COPIER XEROX

XERTR1012	Xerox Drum 1012	(013R00030)
XERTR1065	Xerox Drum 1065/5065/5365	(001R00085)
XERTR2510	Xerox Drum 2510/11/15/20/3030/50/60/2340	(001R00552)
XERTR4220	Xerox Drum 4220	(013R00051)
XERTR4230	Xerox Drum 4230 Fusercart.	(013R00088)
XERTR4235	Xerox Drum 4235/DCC35	(013R00036)
XERTR4850	Xerox Drum 4850	(001R00112)
XERTR5007	Xerox Drum 5007	(013R90002)
XERTR5012	Xerox Drum 5012/14	(013R00022)
XERTR5080	Xerox Drum 5080/3080/90	(001R00086)
XERTR5090	Xerox Drum 4135/4635/5090/5390/DT135	(001R00088)
XERTR5100	Xerox Drum 5100	(001R00119)
XERTR5113	Xerox Drum 5113	(001013R86)
XERTR5210	Xerox Drum 5210/5220	(020E18410)
XERTR5314	Xerox Drum 5312/5314	(013R00065)
XERTR5317	Xerox Drum 5017/5317	(013R00054)
XERTR5320	Xerox Drum 5320/22/5622	(013R00057)
XERTR5380	Xerox Drum 5380/85	(001R00115)
XERTR5614	Xerox Drum 5614	(113R00081)
XERTR5750	Xerox Drum 5750/60/65/90	(001R00123)
XERTRXC23	Xerox Drum XC23	(013R00544)
XERTRXE60	Xerox Drum XE60/62/80/82/84	(013R00553)
XERTRXD104	Xerox Drum XD100/102/103f/104/120f/155df	(013R00551)
XERTRXC520	Xerox Drum X520/XC540/560/580	(113R00105)
XERTRXC810	Xerox Drum XC810/1120/22/30/55/75/XC1020/33/40/44/45/1245/55	(013R00544)
XERTR4010	Xerox Print Cart. 4010/11	(013R00064)
XERTR4030	Xerox Print Cart. 3010/4030/6522	(013R00033)
XERTR5046	Xerox Print Cart. 5046/47	(013R00017)
XERTR5009	Xerox Copy Cart. 5009/5208/5308/09/10	(013R00059)
XERTR5018	Xerox Copy Cart. 5018/28/34/5321/28/33 (WITHOUT COUNTER)	(013R00013)
XERTR5018M	Xerox Copy Cart. 5018/28/34/5321/28/33 (WITH COUNTER)	(013R00009)
XERTR5334	Xerox Copy Cart. 5334/5824/26/28/30	(013R00068)
XERTR5334	Xerox Copy Cart. 5334/5824/26/28/30	(013R00068)

Art.Nr. ORIGINAL DEVELOPER COPIER XEROX

XERD1025	Xerox Developer 1025/38/5022/25/26/27/30/5331/32	(005R90092)
XERD1050	Xerox Developer 1050/5051/52/53/5345/55 (2 x Dev.)	(005R90157)
XERD2510	Xerox Developer 2510/11/15/20	(005R00178)
XERD5007	Xerox Developer 5007	(005R90149)
XERD5018	Xerox Developer 5018/28	(502530836)
XERD5090	Xerox Developer 4135/4635/5090/5390/DT135 (2 x Dev.)	(005R90095)
XERD5100	Xerox Developer 5100 (425K)	(005R90152)
XERD5340	Xerox Developer 5320/22/40/50/52/5665/5837	(005R90180)
XERD3030	Xerox Developer 3030/50/60	(005R90179)
XERD5380	Xerox Developer 5380	(005R90166)
XERD5614	Xerox Developer 5614	(050K22430)
XERD5750BK	Xerox Developer 5750 black	(005R90217)
XERD5750C	Xerox Developer 5750 cyan	(005R90218)
XERD5750M	Xerox Developer 5750 magenta	(005R90219)
XERD5750Y	Xerox Developer 5750 yellow	(005R90220)
XERD5760BK	Xerox Developer 5760 black	(005R90188)
XERD5760C	Xerox Developer 5760 cyan	(005R90189)
XERD5760M	Xerox Developer 5760 magenta	(005R90191)
XERD5760Y	Xerox Developer 5760 yellow	(005R90190)

XEROX



Art.Nr.	ORIGINAL SUPPLIES		XEROX
XERT7020RE	Xerox Imag. Cart. 7020/7021	(1 x 200m) Refill	(003R96497)
XERT7024RE	Xerox Imag. Cart. 7024	(1 x 200m) Refill	(003R91226)
XERT7033	Xerox Imag. Cart. 7033	Refill	
XERT3002	Xerox Ink Cart. 3002/4/6/4004/7015/XJ4C/6C/C6/8/450cp		(008R07638)
XERT3003C	Xerox Ink Cart. 3003/7001/51	(Printhead 3-colour)	(108R00308)
XERT3003D2	Xerox Ink Cart. 3003/7001/51	(1 x Printhead + 2 x Refill)	(108R00312)
XERT3003RE	Xerox Ink Cart. 3003/7001/51	(2 x Refill)	(108R00310)
XERT4020	Xerox Ink Cart. 4020	(2 x 5ccm)	(008R02302)
XERT750PHB	Xerox Print Head M750/760 black		(008R07969)
XERT750PHC	Xerox Print Head M750/760 colour		(008R07970)
XERT750BK	Xerox Ink Cart. M750/760 black		(008R12728)
XERT750BKH	Xerox Ink Cart. M750/760 black	High Cap. (H100)	(008R07971)
XERT750C	Xerox Ink Cart. M750/760 cyan	(Y101)	(008R07972)
XERT750M	Xerox Ink Cart. M750/760 magenta	(Y102)	(008R07973)
XERT750Y	Xerox Ink Cart. M750/760 yellow	(Y103)	(008R07974)
XERT750MPB	Xerox Ink Cart. M750/760 Multipack black	(2 x Ink)	(008R12663)
XERT750MPC	Xerox Ink Cart. M750/760 Multipack cyan	(3 x Ink)	(008R12664)
XERT750MPM	Xerox Ink Cart. M750/760 Multipack mag.	(3 x Ink)	(008R12665)
XERT750MPY	Xerox Ink Cart. M750/760 Multipack yellow	(3 x Ink)	(008R12666)
XERTC11BK	Xerox Ink Cart. C11 black		(008R07903)
XERTC11C	Xerox Ink Cart. C11 3-colour		(008R07904)
XERTC6PBK	Xerox Printhead C6/8 black		(008R07990)
XERTC6PC	Xerox Printhead C6/8 colour		(008R07999)
XERTC6BK	Xerox Ink Cart. C6/8 black	(2 x Ink)	(008R07994)
XERTXJ4D	Xerox Printhead XJ4C colour		(008R07659)
XERTXJ6D	Xerox Printhead XJ6C/450cp colour		(008R07871)
XERTXJ4BX	Xerox Ink Cart. XJ4C/6C/C6/8/450cp black		(008R07660)
XERTXJ4C	Xerox Ink Cart. XJ4C/6C/C6/8/450cp cyan		(008R07661)
XERTXJ4M	Xerox Ink Cart. XJ4C/6C/C6/8/450cp magenta		(008R07662)
XERTXJ4Y	Xerox Ink Cart. XJ4C/6C/C6/8/450cp yellow		(008R07663)

Art.Nr.	ORIGINAL SUPPLIES		XEROX
XERTXJ8BK	Xerox Ink Cart. XJ8C/C20/NC20/470cx/480cx black		(008R07881)
XERTXJ8BK3	Xerox Ink Cart. XJ8C/C20/NC20 black	(3 x Ink)	(008R07978)
XERTXJ8C	Xerox Ink Cart. XJ8C/C20/NC20/470cx/480cx 3-colours		(008R07880)
XERTXJ8PH	Xerox Ink Cart. XJ8C/C20/NC20/470cx/480cx photo		(008R07883)
XERTP8E	Xerox Print Cart. XP8E/WC385		(113R00296)
XERTDC520	Xerox Print Cart. DC520		(106R00058)
XERT212	Xerox Print Cart. DC212/214		(113R00286)
XERT220G	Xerox Print Cart. DC220/230/420	(cap. 19.400)	(113R00276)
XERT1202	Xerox Print Cart. P1202		(106R00398)
XERT1210K	Xerox Print Cart. P1210		(106R00441)
XERT1210G	Xerox Print Cart. P1210 High Cap.		(106R00442)
XERT535	Xerox Toner Cart. Pro 535/545	(2 x Toner)	(106R00370)
XERT555	Xerox Toner Cart. Pro 555/575		(106R00401)
XERT610	Xerox Toner Cart. Pro 610		(006R00833)
XERT635	Xerox Toner Cart. XW 635/645/657		(106R00365)
XERT665	Xerox Toner Cart. Pro 665/765		(106R00405)
XERT735	Xerox Toner Cart. Pro 735/745		(106R00369)
XERT3010	Xerox Toner 3010	(1 x 500g)	(006R90167)
XERT7041	Xerox Toner 7041/42	(2 x 80g)	(006R00713)
XERTR535	Xerox Drum Pro 535/545	UNIT incl. Tonercart	(113R00295)
XERTR610	Xerox Drum Pro 610		(013R00532)
XERTR735	Xerox Drum Pro 735/745		(113R00438)
XERTR3010	Xerox Drum 3010		(013R00045)
XERTR7041	Xerox Drum 7041	UNIT	(013R00076)